



# Sony Reader Touch Edition PRS-600 Back Cover Replacement

This guide shows how to replace the back panel of the device

Written By: Terrika Ngobili





## TOOLS:

- [Phillips #000 Screwdriver](#) (1)
-

## Step 1 — Back Panel




- Using the Phillips head screwdriver PH000, remove the two 1.4 mm screws that are located on the backside of the device.

## Step 2



- Slide the back cover off by pushing it to the left, away from the side that held the screws.
- Remove the cover.

## Step 3



- This is what the device should look like once the back cover panel has been removed.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-04 01:43:12 AM.